

Understanding System III Identifiers (Receiver Signals)

01/02/2024 2:11 pm EST

This is a breakdown of the System III Identifiers (Surgard).

("0", Protocols.SIA);

("1@", Protocols.HeartBeat);

("1", Protocols.Basic);

("3", Protocols.DVAC);

("4", Protocols.CallerID)

("5", Protocols.ContactID);

("6", Protocols.ModemII);

("7", Protocols.Sescoa);

("8", Protocols.AdemcoHighSpeed);

("9", Protocols.Acron);

("C", Protocols.SKFSK);

("E", Protocols.SKFSK);

("F", Protocols.SKFSK);

("G", Protocols.CESA);

("H", Protocols.Robofon);

("I", Protocols.ITI);

("J", Protocols.FBI);

("L", Protocols.Outel);

("N", Protocols.Stratel);

("P", Protocols.DMP);

("Q", Protocols.ContactID);

("a", Protocols.Paradox);

("R", Protocols.SIA);

("S", Protocols.SIA);

("T", Protocols.Telenot);

("U", Protocols.InternationalCallerID);

("V", Protocols.Vonk);

("W", Protocols.Westec);

("Y", Protocols.Surtec);

("Z", Protocols.Basic);

("e", Protocols.ADTPulse);

("s", Protocols.SIMNumber);

("u", Protocols.CallingName);