

OpenEye Oscar

01/10/2024 5:02 pm EST

Video Type: OPENEYE

Connection Type: IP

Access Type: Direct connect to device (URL)

Notable Features, Limitations, and Recommended Usage:

Typical Configuration: OpenEye server accessible via IP by the Central Station.

Software: The OpenEye Oscar API is included in the install of VCC.

API Version: Oscar API 1.3.1.37

Available Options:

- Live Video
- PTZ (if supported by camera)
 - Direct control
- Live Audio (if supported by camera)
 - Listen
- Recorded Playback
- Image Snapshot (to file, clipboard, or history)
- Video Clip Export (to file or history)

Device Address Syntax:

IP Address: ###.###.###.###

or

Resolvable DNS Name: server.somewhere.com

Device Option Syntax:

<parameter>=<value>&<parameter>=<value> ...

Available User Options:

<parameter>= <value>	Acceptable Values	Description
-------------------------	-------------------	-------------

camera=<int>	Single integer starting from 1	Camera number for this device. Required
user=<string>	Any string	The username that has permission to view live video on the camera. Required
password=<string>	Any string	The password for the user. Required
port=<int>	Integer	TCP port number used to connect to the device. Required
stun=<string>	Any string	Stun server if using OpenEye cloud services. Required if using OpenEye cloud services
company=<string>	Any string	Company ID if using OpenEye cloud services Required if using OpenEye cloud services
device=<string>	Any string	Device ID if using OpenEye cloud services Required if using OpenEye cloud services

Supporting Material

[Video Control Center - OpenEye Video](#)